


Blue 7 Chair Assembly Instructions

The following instructions apply to the Plydea Blue 7 Chair. Note that parts are called out in **blue**. If you have any questions, please feel free to contact us at plydea.com!



Pic 1

Use two hands for fifteen parts:


- 2 sides
- 1 back
- 1 seat
- 1 back spreader
- 2 back spreader stiffeners
- 1 stretcher bar (for back spreader)
- 1 front spreader
- 2 arms
- 2 rear arm struts
- 2 forward arm struts



Pic 2

choose the faces of the **sides** you wish to be on the outside. Start the tabs of the **back** into the slots on the **side**, you will need to bend the top of the **side** to conform to the curve of the **back**, push the **back** down until the **back** tabs lock into the **side** slots

repeat for the other **side**




Pic 3

back is down and locked when the top of the **back** is flush with the tops of the **sides**.



Pic 4

push the tabs on one side of the seat right into their slots one side...




Pic 5

then the other...




Pic 6

pull forward...



Pic 7
until it locks into our clever little locks on both sides as shown




Pic 8
choose the face of the back spreader you wish to see and install the stiffeners on the other face in the orientation shown.



Pic 9
push 'em down as far as they will go to engage




Pic 10
engaged!




Pic 11
with the stiffeners down engage the foot slot of the back spreader into the long foot slot of one side and carefully push it away from you tensioning one side's leg. **Caution:** parts under tension at this point, they could recoil and hurt you.



Pic 12
bend the other side's leg away so it will engage too. **Caution:** parts under tension at this point, they could recoil and hurt you.




Pic 13
grab the [stretcher bar](#)



Pic 13
...start it into these slots in a side as shown pushing one end past where it will ultimately engage so you can lock the other end.




Pic 13
one end of [stretcher bar](#) locked into one side.



Pic 14

carefully pull the middle of the **stretcher bar** up into bending to lock its other end. Now making sure the bottoms of the feet are even -- pull the **back spreader** up past the edge of the **stretcher** until the flange on it locks into the long slot in the stretcher. Note that when fully engaged the outside feet tabs of the **back spreaders** will rotate locking into the feet tabs of the **sides**.



Pic 15

desired face of the **front spreader** out




Pic 16

as before, start one foot, then the other




Pic 17

and making sure the bottoms of the feet are even... **Caution:** parts under tension at this point, they could recoil and hurt you.




Pic 18

and with the chair on its back cautiously push the **front spreader** under the **seat** until the tabs snap into the receiver slots in the front of the seat. **Caution:** parts under tension at this point, they could recoil and hurt you so keep fingers clear. Note that when fully engaged the outside feet tabs of the **front spreaders** will rotate locking into the feet tabs of the **sides**.



Pic 19

all snapped in



Pic 20

grab an **arm** with chosen face up, in this picture the ends closest the floor go towards the chair **back**. Also, just to confuse you the arm in my right hand is the chair's left **arm**...



Pic 21

place the **arm** over the tabs and squeeze downward...




Pic 22

...while pushing towards the back to engage tabs fully.



Pic 23

now lift the back-most arm tab and lock into its receiver as shown, in then down to lock. Same deal on the other side...



Pic 24

arm struts come in two varieties. the rear arm struts have a little notch on the middle ball which I'm pointing to.



Pic 25

put the top ball slot into the rear outside arm slot and the notched middle ball into the chair side slot.



Pic 26

gently pull and bend until rear arm strut passes into its receiver then push it down to lock.



Pic 27

down and locked



Pic 28

do the same with the forward arm strut, remember the forward arm struts have no notch in the middle ball and will lock toward the front of the chair... they will put tension on the chair front so you may have to burn a few calories.



Pic 29

forward and locked.

repeat that entire process with the [arms](#) and [struts](#) on the other side...



Pic 30

et voila! sit down. you deserve it!

Enjoy your Blue 7 Chair!

Send us your thoughts:
feedback@plydea.com

...and please go onto plydea.com to give us a rave review!